

Version	Revision Notes
3.18.12	Fix D5100 Audio Mute issue when changing Encoder Source from Analog to HDMI
3.18.10	Update MV5 Scaler firmware to version 00007 Update IP.EXPANSION_PORT and IP.FA_ENABLED keys for valid platforms Fix Duet-5 to allow units to properly discover Dante/Duet presence during a factory reset Fix volume control for D5100 analog audio output Fix AUDIO.MUTE in audio driver, keep analog muted after driver re-initialization
3.18.9	Add Native AES67 for non-Duet-5 encoders and decoders Add extra MV5 PIP options and presets Update MV5 Scaler firmware to version 00005,00006 Fix IR mode vs GPIO functionalitly in X5200/DuetX-5
3.18.8	Add Model and Codec info to codec_reg display Add IP.EXPANSION_PORT modalities SEPARATE and DISABLED Add BT.ON web GUI option Add Color Check for 1080p and 4k Add function/debug Buttons to Preview Page Add extra feedback in MV5 API replies Update MCU FW to version 00004 Update IP.MTU Parameter Update USB Speaker code Update Dante Control Code to add mute functions Update PIP positioning recall and timing Fix display of audio info web GUI (Monitor and Diagnostics) Fix bug when characters CRC appear in UNIT.ID causing default UNIT.ID Fix VIDEO.SOURCE_TIMEOUT in Config web page Fix yellow loading bar on Config Page Fix GUI handling of IP.EXPANSION_PORT with IP.VLAN_TRUNK_MODE and IP.FA_ENABLED Fix Dante STREAM.AUDIO Fix analog audio input Fix analog audio output at startup or source change Fix pop in analog audio output during channel change Fix Audio Source Select indexing Fix MCU SAVE

3.13.56	Add GPIO to X5100 Add SRC MUTE for rework units that use SOC GPIO instead of Ultimo GPIO Update btm_button debounce to match 4 series Fix Analog Volume Control on D5100
3.13.54	Add API control over Power and Link LEDs Add direct re-connect to same host after going into VIDEO.OUTPUT=STANDBY/LOGO/OFF Add API control over Power and Link LEDs Add new default Splash Screen image Re-enable Dante options in GUI Fix audio issue with wallplates when no HDMI connected Fix wallplate audio routing issues Fix display of decoder and encoder IP addresses on Splash Screen Fix javascript error when attempting to save Config Page GUI on E5-WP Fix E5-WP no analog audio Fix non-defaulted parameter state in GUI Fix for SRC ticking with MOD-DANTE-5
3.13.46	First public release
Known Issues	WP Analog or BT audio to Dante drops and clicks if HDMI is removed Swapping of Power and Link LEDs on MV5 devices VIDEO.SOURCE_TIMEOUT defaults to FALSE