ONLINE-TRAINING (INDEX.HTML)

SELF SERVE M.P.R. PROJECTOR

INTERACTIVE TRAINING CONTROL INTERFACE, USE YOUR MOUSE TO HOVER OVER SECTIONS, CLICK TO ACTIVATE



MUTE

SELF-SERVE

AUDIO VISUAL CONTROL SYSTEMS: STANDARD OPERATING PROCEDURE

Selecting the Projector will display all of the controls needed to route Video, Power on and off the projector and deploy the screen.
(PLEASE READ IMPORTANT NOTES REGARDING THE SCREEN)

To send a source to the projector, make sure the screen is down, power on the projector and select the device or input you wish to send to the projector. The device selection is immediate, however please give the system time to make that switch.

Power on and off the projector as needed. Please note that there is a startup time before you will see an image, and likewise a cool down time for the projector operation. If you attempt to power down the projector before the startup procedure has finished, the system will not shut down the projector.

SCREEN DEPLOYMENT: The screen is deployed by a low voltage relay, there is no electronic feedback to inform the control system of the stage the projection screen is at. In order to use, you must fully deploy the screen and wait until the screen has finished it's full deployment and stopped before you select it to retract.

Example, select screen down and wait until it fully stops, once it stops, you can select screen up.

© Copyright **ACS Advanced Cable Solutions**. All Rights Reserved

Advanced Cable Solutions, 26074 Avenue Hall, Ste.1, Valencia, CA 91355. acscabling.com (https://acscabling.com//)

^
(pow