MIXER MODE

INTERACTIVE TRAINING CONTROL INTERFACE, USE YOUR MOUSE TO HOVER OVER SECTIONS, CLICK TO ACTIVATE



MIXER MODE:

AUDIO VISUAL CONTROL SYSTEMS: STANDARD OPERATING PROCEDURE

Selecting Mixer Mode, mutes the Self Serve Audio portions and routes all audio through the Soundcraft Mixer.

The Soundcraft Mixer is a virtual mixer, it is programmable to an end user's settings. The end user has full control over EQ and other audio settings.

Getting used to the Soundcraft Mixer can take some time, we advise you download the manual and watch the help videos located in the FAQ section.

Mixer Mode settings will remain on, until the end user deactivates them, normally after a show or presentation.

To advise an end user that Mixer Mode is active, a warning will display on each touch panel page until it is de-activated.

© Copyright **ACS Advanced Cable Solutions**. All Rights Reserved

Advanced Cable Solutions, 26074 Avenue Hall, Ste.1, Valencia, CA 91355. acscabling.com (https://acscabling.com//)

^
(pow