CONTROL INTERFACES

IN ROOM AVR TOUCH PANEL

Each class room has a touch panel located in the rack. The Projection Control System has a touch panel located on the Sound Operators desk.

Activation is simply by touch or vicinity. Operation of the menus will be covered in the next section.

C1 AUDIO CONTROL

The C1 Audio Control is a user friendly network enabled audio control device.

Turn the rotary knob up or down to raise or lower the volume, press to mute or un-mute. These are located in the Ticket Office, Stagecraft and Lobby areas.

WALL INPUT PLATES

These plates allow youto BYOD (Bring your own device) You simply plug from your device, into the Media Input Plate, then select the Input Plate from the Touch Panel.



TOUCH PANEL

Crestron Touch panel. Single touch activation.

DIGITAL WALLPLATE INPUT

Crestron HDMI/VGA input plate. Audio follows video, however if using VGA, you must also connect your audio computer jack to the plate.



This is a custom Input/Output plate which allows you to connect up microphones and the Audio Mixer to this position.



TIES TO FOH FLOOR BOX

This is a another custom Input/Output plate which allows you to connect up microphones and the Audio Mixer to this position.





PATCHING FOR FOH MADI

This is a network patch panel allowing you to connect to the Control Network. This image shows you how to patch the MADI I/O frame to the system.

C1 VOLUME CONTROL

© Copyright **ACS Advanced Cable Solutions**. All Rights Reserved

Advanced Cable Solutions, 26074 Avenue Hall, Ste.1, Valencia, CA 91355. acscabling.com (https://acscabling.com//)

^
(tpty